

Anziehvorschrift Zylinderkopf**Tightening Instructions for Cylinder Head****Instructions de serrage pour culasse****Prescripciones de apriete para culatas****157.351**passend für / suitable for
adaptable à / adaptable a**Renault/Opel/Volvo/Nissan****Das Original**Schraubenkopf / Head shape Anziehreihenfolge/Tightening sequence/Ordre de serrage/Orden de apriete
Tête de vis / Cabeza de tornillo272.010
M12x1,5x121Anziehen/
Tightening/
Serrage/
Apriete
 30 Nm
 230°
Zeichenerklärung / Explanations / Explication / Explicacion

	neue Zylinderkopf-schrauben verwenden	use new cylinder head bolts	utiliser des vis neuves	emplar tornillos nuevos
*	Warmlauf (80°C)	warm up time (80°C)	chauffage (80°C)	calentamiento (80°C)
	Schrauben einzeln lösen und wieder anziehen	loosen and tighten each bolt	deserrer et serrer vis par vis	aflojar y apretar tornillo a tornillo
●	Setzzeit	relaxation time	durée de tassement	tiempo de espera
➤	Drehwinkel	torque angle	angle de serrage	ángulo de giro

Motortyp / Engine type / Type de moteur / Tipo de motor

Ø: 81 mm; ÷: 1,32 mm

Mot: F9Q 664,670,674,680,710,716-718,
731-733,736,738,740,744,750,754,
756,758-760,762,770,772,774,780,
782,790,800,803,804,808,812,816

Kangoo, Laguna, Master, Megane, Scenic, Movano

Elring-ServiceteamFon +49 7123 724 799
Fax +49 7123 724 798
service@elring.de

23/11/14

157.351